



## INSTALLATION INSTRUCTIONS FOR FERRARI 308, 328, Mondial CARBON FIBER INLET TUBE

Thank you for choosing to purchase a Carbonio product. Please take the time to fully read over these instructions before attempting to install the kit. This will greatly speed up the installation process and minimize any difficulties you may encounter.

### **Tools Required:**

- Flat head (slot) screwdriver

### **Kit includes:**

1 – Carbon fiber inlet tube  
1 – Straight rubber coupler  
1 – Anti-vibration ribbed coupler  
4 – Stainless steel hose clamps

**Step 1:** Loosen the two hose clamps holding the OEM ribbed inlet tube in place and remove this tube.

**Step 2:** Place the 4 included stainless steel hose clamps loosely over the ends of the included rubber couplers

**Step 3:** Slide the straight rubber coupler approximately 1" onto the short end of the carbon fiber tube

**Step 4:** Place the corrugated fitting onto the lower metal air tube and tighten the clamp

**Step 5:** Slide the assembly prepared in Step 3 onto the throttle body

**Step 6:** Rotate/ Wiggle the lower (angled) end of the carbon fiber tube into the top of the ribbed fitting installed in Step 4.

**Step 7:** Adjust the fit as necessary and tighten the remaining 3 clamps. DO NOT OVERTIGHTEN.

## LABOUR ESTIMATE GUIDE

5-10 Minutes