



INSTALLATION INSTRUCTIONS FOR CARBON FIBER AIRBOXES LAMBORGHINI GALLARDO COUPE, SPYDER, & SUPERLEGGERA

Thank you for choosing to purchase a Carbonio product. Please take the time to fully read over these instructions before attempting to install the kit. This will greatly speed up the installation process and minimize any difficulties you may encounter.

Tools Required:

- Flat head (slot) screwdriver

Kit includes:

- 2 – Carbon fiber replacement airbox lids

Step1: Using a flat head screwdriver loosen the following:

- The 4 screws on each airbox lid that fasten the lid to the airbox body
- Back off the hose clamp that attaches the airbox lid to the 'S' shaped inlet hose
- On the drivers side airbox, loosen the hose clamp that attaches the rubber air pump hose to the airbox lid.

Step 2: With all of the screws and clamps loose. The airbox lids can be removed from the car. Note that the OEM airbox lids sometimes stick a little and a flat head screwdriver may be needed to GENTLY pry the lids loose.

Step 3: Once the OEM airbox lids are removed, check all mounting surfaces and hoses for signs of deterioration or damage. Repair or replace damaged parts as necessary

Step 4: Installation of the carbon airboxes are the reverse of the removal. Be sure to fit the new airboxes in place and slide all hoses into position before tightening anything down.

Step 5: Tighten down all screws and clamps being careful not to over-tighten.

LABOUR ESTIMATE GUIDE

10 Minutes