



## **INSTALLATION INSTRUCTIONS FOR CARBON FIBER ENGINE BAY PANELS LAMBORGHINI GALLARDO COUPE, & SUPERLEGGERA**

Thank you for choosing to purchase a Carbonio product. Please take the time to fully read over these instructions before attempting to install the kit. This will greatly speed up the installation process and minimize any difficulties you may encounter.

### **Tools Required:**

- Torx T20 screwdriver or socket
- 10mm socket

### **Kit includes:**

- 1 – Exhaust cover
- 2 – Side trim panels
- 1 – Forward firewall panel
- 1 – Under bonnet panel (if chosen as part of kit)
- 8 – Clear abrasion protectors

**Step1:** Using a Torx T20 screwdriver remove the engine bay panels in the following order:

1. Exhaust cover
2. Left side trim panel
3. Right side trim panel
4. Firewall panel
5. Under bonnet panel (if applicable)

Note that the removal of the side panels and under bonnet panel will require the removal of the shocks that hold the bonnet open as well as the ball studs the shocks mount to. A 10mm socket can be used to remove the ball studs.

**Step 2:** With all of the panels removed, transfer any mounting clips, spacers, rubber trim or other hardware from the OEM panels to the carbon pieces

**Step 3:** Once the carbon parts have the hardware transferred to them, installation must be done in the reverse order of removal.

**Be sure to start all fasteners before tightening them down. Failure to do this will result in problems with fit**

**Step 4:** Tighten down all screws being careful not to over-tighten.

**Step 5:** Carefully check the closure of the rear bonnet. If there is any rubbing between the under bonnet panel and the rest of the carbon panels, apply the included clear abrasion protectors to those areas to keep from damaging the carbon finish.

**LABOUR ESTIMATE GUIDE**  
**3 Hours**