



## INSTALLATION INSTRUCTIONS FOR 2009+ Lamborghini LP560-4 & LP550-2 FRONT SPOILER

Thank you for choosing to purchase a Carbonio Intake System. Please take the time to fully read over these instructions before attempting to install the kit. This will greatly speed up the installation process and minimize any difficulties you may encounter.

### Tools Required:

- Torx T-20 socket tip

### Kit includes:

1 – Carbon fiber replacement front spoiler

### Step 1:

If installation is not taking place on a vehicle hoist, lift the nose of the car using the parking height controller located on the interior center console.

### Step 2:

Using a T20 Torx socket tip remove the 3 screws that hold the OEM plastic mesh in place over the stock spoiler.

Then remove the 9 screws (4 on the top and 5 on the bottom) that hold the OEM spoiler in place. With the screws removed the OEM spoiler can be removed by pulling it out



### Step 3:

Installation of the carbon fiber spoiler is the reverse of the removal.

TIP: Be sure to start all the screws before tightening them down. This will ensure proper alignment of all of the mounting holes.

**LABOUR ESTIMATE GUIDE**  
30 Minutes