



INSTALLATION INSTRUCTIONS FOR CARBON FIBER ENGINE BAY PANELS LAMBORGHINI SUPERLEGGERA

Thank you for choosing to purchase a Carbonio product. Please take the time to fully read over these instructions before attempting to install the kit. This will greatly speed up the installation process and minimize any difficulties you may encounter.

Tools Required:

- Torx T20 screwdriver or socket

Kit includes:

2 – Side trim panels
1 – Forward firewall panel

Step 1: Using a Torx T20 screwdriver remove the engine bay panels in the following order:

1. Left side trim panel
2. Right side trim panel
3. Firewall panel

Step 2: With all of the panels removed, transfer any mounting clips, spacers, rubber trim or other hardware from the OEM panels to the carbon pieces

Step 3: Once the carbon parts have the hardware transferred to them, installation must be done in the reverse order of removal.

Be sure to start all fasteners before tightening them down. Failure to do this will result in problems with fit

Step 4: Tighten down all screws being careful not to over-tighten.

LABOUR ESTIMATE GUIDE
1 Hour